

PA28-181 PIPER ARCHER III CHECKLIST

EAST COAST AERO CLUB

PREFLIGHT	LEFT WING	LEFT MAG (upper panel)ON StarterENGAGE RIGHT MAG (upper panel)ON Throttle800 RPM (No Higher Than 1000) Oil pressure.....CHECK Fuel pumpOFF MixtureLEAN
COCKPIT SAFETY CHECK		
MagnosOFF MixtureCUTOFF ThrottleCLOSED	General conditionCHECK & CLEAR Fresh air inletCHECK Main gear & brakeCHECK Fuel tank ventCHECK Fuel tank sumpDRAIN & NO DRIPS Fuel tankCHECK Fuel cap & ventCHECK Stall Strip (if installed)CHECK Tie down/chockREMOVE Pitot Tube (3 holes)CHECK WingtipCHECK Ailerons & static wicks (if installed)CHECK FlapCHECK	
Hobbs & TachRECORD Documents (A(R)ROW)CHECK Flight controlsRELEASE Parking brake releasedAS REQUIRED Avionics/RadiosOFF Electrical switchesOFF StrobesON Master switch (upper panel) PROP CLEARON Fuel gaugesCHECK Annunciator PanelCHECK IF IFR OR NIGHT FLIGHT Aux vacuum pump <u>ON FOR 1 SECOND</u>CHECK Exterior lightsON, CHECK, OFF <u>DAY - Landing Lights, & Strobes</u> <u>NIGHT - Landing Lights, Strobes & Nav Lights</u> Pitot heatON, CHECK, OFF <u>(ONLY IF REQUIRED)</u> Stall hornCHECK Exterior lights (& Pitot heat)OFF Master switchOFF AltimeterFIELD ELEVATION Magnetic compass & deviation card.... CHECK Pitot & static drainsDRAIN Flight controlsCHECK FlapsEXTEND Fire extinguisher (if installed)CHECK WindowsCHECK	General conditionCHECK AntennasCHECK Fresh air inletCLEAR	
RIGHT WING	LEFT FUSELAGE	
General conditionCHECK & CLEAR FlapCHECK Ailerons & static wicks (if installed)CHECK WingtipCHECK Tie down/chockREMOVE Stall Strip (if installed)CHECK Fuel tank ventCHECK Fuel tank sumpDRAIN & NO DRIPS Fuel tank quantityCHECK Fuel cap & ventCHECK Main gear & brakeCHECK Fresh air inletCHECK	StabilatorCHECK & CLEAR Trim tab & NutCHECK & CLEAR RudderCHECK & CLEAR AntennasCHECK Tie down / LockREMOVE	
NOSE	EMPPENNAE	
General condition & leaksCHECK CowlingSECURE Oil (6 Qts)CHECK Propeller & spinnerCHECK Alternator belt tensionCHECK Air inletsCHECK Nose gearCHECK Chocks (If in place)REMOVE TOW BARREMOVED AND STOWED Fuel strainerDRAIN & NO DRIPS	General ConditionCHECK AntennasCHECK Baggage areaSECURE Baggage doorUNLOCKED & LATCHED	
FREQUENCIES	PRACTICE AREA - ALL123.5	EMERGENCY (GUARD) 121.5
HANSCOM - KBED	NORWOOD - KOWD	NASHUA - KASH
ATIS124.6 GROUND121.7 TOWER118.5 BOS APP124.4 Signature (or 781-274-0010).....130.8	ATIS119.95 GROUND121.8 TOWER126.0 BOS APP120.6 / 124.1 Flight Level (or 781-769-8680)129.42	ATIS125.1 GROUND121.8 TOWER133.2 BOS APP124.9 Infinity (or 603-598-4526).....129.75

PA28-181 PIPER ARCHER III CHECKLIST

EAST COAST AERO CLUB

TAKEOFF

Mixture (below 3000') RICH
 Throttle FULL
 Power 2240-2340 RPM=STATIC CHECK
 Engine gauges CHECK
 Airspeed CHECK
 Rotate (0°/25°) 60 / 55 KIAS

CLIMB

Flaps.....RETRACT AT SAFE SPEED (60 KIAS)
 Airspeed (cruise climb) ... 87KIAS/500'/MIN
 Fuel pump OFF CHECK PRESSURE
 Oil pressure & Temp CHECK

CRUISE

Power AS REQUIRED
 Mixture.....LEAN AS REQUIRED

FUEL TANK SWITCH

Place to land in emergency IDENTIFY
 Fuel pump ON
 Fuel selector DESIRED TANK
 Fuel pump OFF
 Fuel pressure CHECK

DESCENT

Fuel Pump ON
 Fuel Selector FULLEST TANK
 Power AS REQUIRED
 Mixture ENRICH / AS REQUIRED
 Carb heat AS REQUIRED
 Seats & seat belts UPRIGHT & SECURE

APPROACH & LANDING

Downwind 90 KTS
 Fuel pump ON
 Fuel selector FULLEST TANK
 Mixture (below 5000') RICH
 Carb heat (if on) OFF SHORT FINAL
 Flaps (<102 KIAS) AS REQUIRED
 Landing (0°) 70 KIAS
 Landing (40°) 66 KIAS

AFTER LANDING

RPM 1000
 Radio GROUND/CTAF
 Lights AS APPROPRIATE
 Flaps RETRACT
 Fuel pump OFF
 Carb heat OFF
 Mixture LEAN
 Pitot Heat OFF
 Transponder 1200

SHUTDOWN

Call for fuel TO TABS AS REQUIRED
 Avionics/Radio master OFF
 Throttle IDLE
 Mixture CUTOFF

WHEN PROP STOPS

Magneton OFF
 Electrical switches OFF
 Strobes LEAVE ON
 Master & Alt switches OFF
 Hobbs & tach RECORD
 Flight controls SECURE
 PARKING BRAKE CHECK RELEASED
 Tie downs SECURE
 (Chocks - if no tie downs)
 Cover ON

SPEEDS

Vr (0°/25°) 60/55 KIAS
 Vg (0° Flaps) 76 KIAS
 Glide distance approx 1 NM per 550'
 Va (2550/1634 lbs) 113/89 KIAS
 Vfe 102 KIAS
 Vy (0°) 76 KIAS
 Vx (0°) 64 KIAS
 Vx (25°) 60 KIAS
 Vs0 48 KIAS
 Vs1 54 KIAS

AIRPLANE SPECS

Usable fuel Tabs 34g / Full 48g
 Taxi fuel 1.4g
 Climb fuel 14.0 GPH
 Max Crosswind 17 KTS
 Cruise 3000'@75% 2560 RPM/122KTS
 Cruise GPH@75% (leaned) 13.5

EMERGENCY PROCEDURES

NOTE: NOT ALL EMERGENCY PROCEDURES

ARE HERE

Check POH for additional procedures

ENGINE FIRE DURING START

Starter CONTINUE CRANKING
 Mixture CUTOFF
 Throttle OPEN
 Fuel pump OFF
 Fuel selector OFF
 Evacuate to rally point

ENGINE POWER LOSS IN FLIGHT

Fuel selector FULLEST TANK
 Fuel pump ON
 Mixture RICH
 Carb heat ON
 Magneton BOTH
 Engine gauges CHECK

POWER OFF LANDING

Trim for best glide 76 KIAS
 Landing area IDENTIFY
 ELT ACTIVATE
 Radio 121.5 / TOWER / APCH MAYDAY
 Transponder 7700
 Final approach (40°) 66 KIAS
 Magneton OFF
 Master switch OFF
 Alternator switch OFF
 Fuel selector OFF
 Mixture CUTOFF
 Seatbelts SECURE
 Door UNLATCH

ENGINE ROUGHNESS

Carb heat ON
 If still rough after ONE MINUTE:
 Carb heat OFF
 Mixture ADJUST TO SMOOTHEST
 Fuel pump ON
 Fuel selector SWITCH TANKS
 Engine gauges CHECK
 Magneton CHECK/SELECT SMOOTHEST
 Mixture RICH
 Land AS SOON AS PRACTICAL

ENGINE FIRE IN FLIGHT

Fuel selector OFF
 Throttle CLOSED
 Mixture CUTOFF
 Fuel pump OFF
 Heater & defroster OFF
 Speed INCREASE TO EXTINGUISH
 Land IMMEDIATELY

LOSS OF FUEL PRESSURE

Fuel pump ON
 Fuel selector CHECK ON FULL TANK

ELECTRICAL (CABIN) FIRE

Master switch OFF
 Alternator switch OFF
 Vents OPEN
 Heater & defroster OFF
 Fire extinguisher AS NECESSARY
 Land AS SOON AS PRACTICAL

FREQUENCIES

PRACTICE AREA - ALL 123.5

EMERGENCY (GUARD)..... 121.5

HANSCOM - KBED

ATIS 124.6
 GROUND 121.7
 TOWER 118.5
 BOS APP 124.4
 Signature (or 781-274-0010).....130.8

NORWOOD - KOWD

ATIS 119.95
 GROUND 121.8
 TOWER 126.0
 BOS APP 120.6 / 124.1
 Flight Level (or 781-769-8680) 129.42

NASHUA - KASH

ATIS 125.1
 GROUND 121.8
 TOWER 133.2
 BOS APP 124.9
 Infinity (or 603-598-4526).....129.75